

INFORMATION SHEET

STRUCTURAL CONNECTIONS

BOLTS, COACH BOLTS, COACH SCREWS AND DOWELS

TYPICAL LOAD-SLIP CURVES FOR DIFFERENT TYPES OF FASTENERS

The information provided below has been taken from the New Zealand Timber Design Guide 2007, published by the Timber Industry Federation and edited by Professor A H Buchanan. To purchase a copy of the Timber Design Guide, visit www.nztif.co.nz

