

# INFORMATION SHEET

## STRUCTURAL CONNECTIONS



### SCREWS

#### LAG SCREW SIZES AND CORROSION PROTECTION

The information provided below has been taken from the New Zealand Timber Design Guide 2007, published by the Timber Industry Federation and edited by Professor A H Buchanan. To purchase a copy of the Timber Design Guide, visit [www.nztif.co.nz](http://www.nztif.co.nz)

**Table 5: Lag screw sizes and corrosion protection**

	Length (mm)										
6	g	g	g	g	g	g					
8	g	g	g	g	g	g					
10	g	ss, g	g	ss, g	g	ss, g	g	g	ss, g	g	
12	g	ss, g	g	ss, g	g	ss, g	ss, g	g	ss, g	g	g

Coating: ss = stainless steel, g = galvanised.